
Installing the Litter-Robot 4 Mini Fence

The Litter-Robot 4 Mini Fence snaps onto the bezel at the globe entrance and acts as a barrier to contain kicked-up litter.





How to install





Hold the fence upright inside the globe.





• Gently push down on the front of the fence to snap it onto the bezel. Make sure the fence is level.



Press the Reset button (a) to zero the weight sensors.